





**Quick Start Guide** 



# **Before Starting**

Dear Valued Customer, thank you for purchasing the XBA Bill Acceptor. The XBA comes equipped with innovative wide-angle banknote insertion technology to offer superior acceptance rate of 98% or higher. With outstanding design, the XBA has the ability to provide a very high degree of resistance to strong ambient light as well as advanced optical and mechanical anti-fishing structure for better investment protection. The built-in USB port allows for convenient firmware upgrades via an USB flash drive.

Before installation, please check that the package contents of the XBA bill acceptor are as listed below:

- ♦ XBA Bill Acceptor
- ♦ Power and Data Communication cable
- ♦ Bill insertion bezel sticker
- ♦ DIP switch setting guide
- Quick Start Guide
- ♦ C25760-R XBA Metal Plate(Option)

Should you have further questions,
XBA Bill Acceptor Installation & Service Manual can be downloaded at:

www.ictgroup.com.tw


Select "Support" from menu, then click "Manual Download".




# **Start Installation**

# Step 1: Confirm the bezel type

There are three types of bezels based on the vending machine requirements. Be sure to choose the bezel you need before ordering/ installation as each bill acceptor comes with only ONE bezel.



Step 2: Select interface






# Step 3: Prepare the connection cable

We provide the cables for MDB, RS232(ICT Protocol), Pulse, ccNet, RS232 A0, JPSTD, GPT Parallel and ccTalk interfaces. Each bill acceptor comes with ONE cable only.

Please select the one you need to connect.











		FIG.03				
Interface	Used Voltage	Usage				
ICT Protocol						
ccNet	12V DC	Power & Data Communication				
RS232 A0						
	WEL-RXBA18					
PIN 1- YELLOW PIN 2- GREEN PIN 5- RED PIN 7- BLUE PIN 8- PURPLE PIN 9- ORANGE	+12V DC INPU REDIT RELAY(N.O. EDIT RELAY(COM	- PIN 2- BLUE				
1 2 3 3 4 4 5 5 6 8 8 8 9 9 9 9 9 172340-1	DC 12/24V	1   6   6   6   6   6   6   6   6   6				
D-SUB 9F	ICT PROTOCOL #WEL-RXBA18	BLK-15*2 30 be				
PIN	2- RXD 3- TXD 5- GND	PIN 10- YELLOWGND PIN 25- REDVCC PIN 26- WHITETX11 PIN 27- BLACKRX11				







Note: XBA ccTalk supports 12/24V DC from CPU board number "399M30" (399M20 or before, support 12V DC only).



# Step 4: Configure the power-saving function

If your control board provides a sleep and wake-up feature (for example a battery-powered vending machine), then it can function with our power-saving mode to minimize power consumption while the machine is idle. This function allows your battery-powered machine to operate longer between chargings.

- Note: 1. The wake-up function is triggered through PIN3 of the WEL-RS7P02 cable.
  - 2. Please do NOT select this mode if your VMC does not support sleep/wake-up feature. It may cause abnormal operation that affects the transaction.

Mode	SW3	SW4
No power-saving mode	OFF	OFF

Mode 1	SW3	SW4
XBA wakes up by bill insertion and then wakes up VMC	OFF	ON


TABLE.02

Mode 2	SW3	SW4	
XBA wakes up by VMC	ON	OFF	TARIF

Mode 1+2	SW3	SW4
XBA wakes up by bill insertion or VMC	ON	ON


TABLE.04

Step 5: Power off the vending machine.





Step 6: Open the door and install the XBA on the vending machine <Standard Bezel or Standard Metal Bezel>




#### Note:

Please hook up the MOLEX 5557-6R connector of WEL-RS7P02 with the ICT coin changer cable if you choose to connect the XBA through it.

#### <TOB-Bezel>


Step 6-1.

Install the mounting frame on the vending machine and ensure it is secured.




Step 6-2.

Hook up the cable with the XBA through the 30-pin connector.




Step 6-3.
Buckle the XBA to the mounting frame.



Step 6-4.

Connect the other end of the cable to VMC to complete the installation.




## Note:

Please hook up the MOLEX 5557-6R connector of WEL-RS7P02 with the ICT coin changer cable if you choose to connect the XBA through it.




### <Standard Metal Bezel>



#### Note:

Please hook up the MOLEX 5557-6R connector of WEL-RS7P02 with the ICT coin changer cable if you choose to connect the XBA through it.

Step 7: Power on the vending machine.



# Step 8: Check the bezel LED

Green(Power Save Mode)/Multi-Color means the bill acceptor is functioning normally; if not please check the rear LED and refer to the chart below.

# Step 9: Transaction testing

Insert bills of each accepted denomination, check if they are accepted and stored into the cashbox. If any problem occurs, please refer to the troubleshooting section in the service manual or contact local ICT distributor.

**Note:** Please refer to the provided DIP switch setting guide to configure more options if necessary.



Step 9-1: Check Bezel LED Error




TABLE.05


LED Flashes		Otatua	0 5 4 5	
Red	Green	Status	Corrective Actions	
	1	White Card Calibration	Please calibrate with ICT white calibration card.	
1		Bill jammed.	Remove the bill box by sliding the top button and the bill path(as FIG.22), and then remove the jammed bill.	
2		Disable.	Inspect the right DIP switch setting.	
3		Recognition sensor module error.	Inspect the foreign objects on sensor or bill path and clean.	
3	1	IR error.	Inspect the foreign objects on sensor or bill path and clean.	
3+2		Hook sensor error.	Inspect the foreign objects on security hook and clean.	
4		Anti-string sensor error or a stringing attempt has detected.	Inspect the foreign objects on sensor or bill path and clean.	
5		Bill box has been removed.	Replace the bill box.	
6		Stacker error or stacker full.	Empty the bill box.	
7		Motor error.	Inspect the foreign objects on bill path and clean.	



Step 9-2: Check Back LED Error

TABLE.06

LED Flashes <b>RED</b>	Status	Corrective Actions
1	White Card Calibration	Please calibrate with ICT white calibration card.
1	Bill jammed.	Remove the bill box by sliding the top button and the bill path (as FIG.22), and then remove the jammed bill.
2	Disable.	Inspect the right DIP switch setting.
3	Recognition sensor module error.	Inspect the foreign objects on sensor or bill path and clean.
3+1	IR error.	Inspect the foreign objects on sensor or bill path and clean.
3+2	Hook sensor error.	Inspect the foreign objects on security hook and clean.
4	Anti-string sensor error or a stringing attempt has detected.	Inspect the foreign objects on sensor or bill path and clean.
5	Bill box has been removed.	Replace the bill box.
6	Stacker error or stacker full.	Empty the bill box.
7	Motor error.	Inspect the foreign objects on bill path and clean.





If the error can not be solved after corrective actions or it recurs, please contact ICT for technical support.